



**Mastercool**<sup>®</sup>  
"World Class Quality"

**90066-EX-HOSE  
EXHAUST HOSE ASSEMBLY  
INSTRUCTION MANUAL**



- Utilize with Mastercool "Black Series" vacuum pumps
- Vent exhaust fumes in tight quarters
- Highly recommended when servicing systems running on A2L and A3 flammable refrigerants

**INSTRUCTIONS:**

1. Unscrew existing exhaust from vacuum pump.
2. Screw new exhaust onto vacuum pump.
3. Put clamp over hose and put hose over smooth part of new exhaust.
4. Tighten clamp around hose and exhaust.
5. Route hose to a safe and well ventilated location.

**PARTS:**

**90066-EX-HOSE**

- |             |   |
|-------------|---|
| 90066-PH    | Clear Plastic Hose by Meter                   |
| 90066-CLAMP | Stainless Steel Clamp                         |
| 90066-EX    | Vacuum Pump Exhaust for 1.5, 3 & 6 CFM models |

⚠ **WARNING:** Cancer and Reproductive Harm – [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

For parts or service please contact the service department 1-888-825-6989