

53000-NGKT CGA580 US STANDARD TIP FITTING FOR NITROGEN GAS INSTRUCTIONS



WARNING

- **WEAR GOGGLES**
- **WEAR GLOVES**

REMOVE THE EXISTING TRACER GAS FITTING

1. Slide the nut towards the regulator to expose the hex on the end of the bullet shaft.
2. Put one wrench on the hex adapter next to the regulator.
3. Put a second wrench on the bullet shaft.
4. Rotate counterclockwise to remove the tracer gas fitting.

PREPARE THE REGULATOR FOR THE N2 ADAPTER

1. Use a round wire brush to remove any residual thread sealant from inside the hex adapter.

INSTALL THE US N2 FITTING.

1. Apply Loctite 271 (Blue) to the first two to three threads on the N2 bullet shaft.
2. Put one wrench on the hex adapter next to the regulator.
3. Put an Allen wrench on the US N2 bullet shaft.
4. Rotate clockwise until tight.

For parts or service contact the service department: 1-888-825-6989